Quick Tips

These tips should work on all Hot Spot Spas and Solana Hot Tubs mfg. from 2002-2007

Tips on the following 2 pages are designed at a "quick" reference.

Always refer to your Owner's Manual for more detailed information.

Filling Your Spa

To minimize airlocks in the equipment, put hose down the center of the filter in the filter compartment. Turn hose on. This will fill the spa through the heater, pumps and jets pushing most of the air out of the lines. Fill the spa to the bottom of the pillows or above the jets.

Follow proper power up procedures detailed in Owner's manual or from delivery start-up sheet. If refilling spa, bring water sample in for analysis.

It is recommended to balance spa water TA, CH and pH immediately after first use, then sanitize within 36 hours.

Spa not heating

- 1. The Spa will stop heating due to low flow through the heater in order to keep the heater from being damaged.
- 2. Check your filter to make sure that it is clean; some heaters have a reset button, refer to owners' manual for location or other tips. It is best to remove the filter from the spa, before resetting the heater/GFCI, because debris in the filters may be restricting the flow and causing the problem. Service calls that are the results of a dirty or clogged filter are <u>NOT</u> covered under warranty and we will have to charge a service call.

Flashing "----" on controls (2006-2007) or flashing 3 diamonds (2002-2005)

- 1. Did you remember to put the hose down the center of the filter area and clean your filter?
- 2. If No, the pump may have an airlock, or the filter may have tripped the hi-limit. Reset the hi-limit (Refer to Owner's Manual) and place a hose down the center of the filter (just like when you fill your spa) to flush out the air. Make sure that the water level is at the correct level.
- 3. Turn spa power off, then make sure there is no foreign debris in the spa, pull the filter out and replace the basket. Turn the power to the spa on and run jets 10 minutes.
- 4. If the flashing "----" stops then the problem has been corrected.
- 5. If the flashing "----" continues, call for service.

Flashing "-.-." on controls

- 1. Turn power to the spa off, take out filter and clean, then turn power back on per start up instructions/ "filling your spa" step 4, replace clean filter and check water level
- 2. If the "-.-." continues to flash, call for service

Locking/Unlocking Spa and/or Locking/Unlocking the Spa's Temperature, on control panel (2006-2007)

- 1. To lock/unlock **the spa**, press the "set" button and then (the word "set" will be flashing) press "temperature up" button once, wait 10 seconds before pressing any other buttons.
- 2. To lock/unlock the **spa's temperature**, press the "set" button and then (the word "set" will be flashing) press "temperature down" button once, wait 10 seconds before pressing any other buttons.

No Jet Pressure/Priming the pumps

Upon filling or refilling the spa, if a pump is operating and water is not flowing from any of its jets, the pump may not be properly primed (have water in it). To correct, refer to the Overhead View and perform the following procedures:

- 1. Turn off power to the spa at the breaker(s) and remover the equipment compartment door.
- 2. Loosen the union on the top of the pump(s) to allow the air to escape. When water is present, hand-tighten the union.
- 3. Turn power back on, activate the pump(s) and check to make sure union is tight enough to keep it from leaking.
- 4. Replace equipment compartment door.

Draining Your Spa (3 times per year minimum)

- 1. Turn the power to the spa off by turning breakers off or unplug from the wall. Follow proper power procedures.
- 2. Locate drain on the front or in the equipment compartment area. See Owner's Manual.
- 3. Attach garden hose and drain
- 4. After your spa is drained then close the drain and replace cap
- 5. Refer to Filling procedures
- 6. If winterizing spa, follow detailed steps in Owner's Manual or contact our store for assistance. Damage caused to your spa by improper winterizing is **NOT** covered by your spa warranty.
- 7. DO NOT change your spa water when the temperature is below freezing.

Breakers/GFCI Tripping – If the breaker(s) or GFCI is continuously tripping, call for service.

Filter - Rinse Filter once a month, (or as needed), soak in recommended filter cleaner every drain (4 months).

Cover - Condition cover monthly with Cover Clean. When cover gets heavy, it will need to be replaced as it will become less energy efficient. Heavy covers can be unsafe and may cause damage to cover assist and/or skirting.

Skirting – Clean as needed according to owner's manual 1. 2. 3. 4. 5. 6. 7.

Rodents – If your spa is going to be placed in an area known to be frequented by ants, termites or like creatures, mice, rats, or other nocturnal creatures it is your responsibility to protect your spa. the manufacturer recommends covering the access opening to the spa's equipment compartment with a heavy gauge screen material available from warehouse supply. Damage to the spa's equipment components or internal plumbing as a result of pest/rodent infestation is <u>NOT</u> covered under your warranty.